


# THE INSIDE

## Peel and Stick Wallpaper Instructions


### TOOLS REQUIRED:



Razor Knife



Plastic Smoother



Steel Ruler  
or Straight Edge



Pencil



Scissors



Tape Measure



Level

\*We recommend  
2 people  
for assembly

### SURFACE PREPARATION

For best results, clean, dry, and smooth all surfaces. Product will not adhere to unclean or textured surfaces. Do NOT apply onto freshly painted (let paint dry for at least 4 weeks). Do NOT apply to lacquered furniture. This product may not work on heavily textured surfaces.

### CLEANING

Our wallpaper is washable and can be cleaned using a mild detergent and a damp sponge or cloth.


### REMOVAL

Start at the top corners gently pulling firmly, evenly and slowly downward, working parallel to the surface.


### STEPS TO APPLYING WALLPAPER

**1** Pre-cut strips to wall height; allow an extra inch on top and bottom for trimming. Make sure to align any design from strip to strip. Cut and trim product with a sharp razor knife.


TIP! Number the back of each strip.




**2** Beginning on the left side of your wall, measure out from the corner the width of each panel (18") and mark the wall lightly with a pencil. Using your level, draw a straight line down to create a guide for your first strip.




**3** Peel about 12" of the backing away from the top of the paper. Apply the paper to the top of the wall, allowing a bit of excess to overlap the ceiling which will be trimmed off later. Align the right side of the strip to your mark and lightly press the edge to the wall along the mark. Reposition if needed to ensure a vertical seam.




**4** Working from top to bottom, pull the backing away and evenly press the paper to the wall a few inches at a time. Be careful not to pull or stretch the material or the pattern will not align. For best results, have one person hold the remaining paper taut and the other person peel off the backing slowly while pressing the paper onto the wall.



**5** Using a plastic smoother or your hand, work your way down and smooth the material to the wall, pushing out any air bubbles.



**6** Trim off excess material at ceiling and baseboard with a straight edge and sharp razor knife.



**7** Repeat procedure aligning your next strip to the right edge of your previous strip.